

PRESSURE CALIBRATOR



Manufactured by Ashcroft the PDTG3089 pressure calibrator has a total error band accuracy of $\pm 0.05\%$ and is supplied with a UKAS traceable factory calibration certificate at -0.9; 0; 1; 2; 3 & 4 bar

The CP916 pneumatic hand pump operates from -0.950 bar to +5bar and the complete pressure calibrator supplied in a carry case.

Part number	PDTG3089-CP916
Pressure range	-0.950bar to +5 bar gauge
Accuracy	$\pm 0.05\%$ [total error band]
Over pressure limit	8bar
Display	5 digits
Operating ambient	-10°C to +50°C

Total error band accuracy includes linearity, hysteresis, temperature and repeatability errors and that all readings from zero to full scale are within the stated accuracy.

One of a range of products from Anville Instruments for sterilizer and washer-disinfector validation to meet standards HTM0101, HTM2010, HTM2030, EN285 & EN584.



Anville Instruments Ltd
Bramble Orchard, 46a Folly Lane North,
Farnham, Surrey, GU9 0HX.

e-mail: sales@anvilleinstruments.com
Main No. +44 (0) 1252 351 030.
Fax: +44 (0) 1252 323 492.

